





## 产品配色与工艺说明图 Product Colour, Material & Finishing Specifications

Product Model 产品型号	AZPB-F001	Brand 品牌	中性	Job No. 图档编码	
Product Type 产品类	无线充电器说明书	Description 描述	/	Revision 版本号	1.0
Dimension 尺寸	90*65mm	Original Designer 原设计师	叶少敏	Date 日期	2015.09.24
Scale 比例	1:1	Technology 工艺	128g哑粉纸 双面四色印刷	Verifying 审核	/

### 无线充电移动电源 用户手册




#### 连接适配器充电




本产品拥有以下两种充电方式：  
① 将电源适配器插在插座上。  
② USB电源线一端连接适配器，一端连接移动电源进行充电。  
③ USB电源线一端连接适配器，一端连接无线充电发射板，将移动电源反过来放置在无线充电发射板上进行充电。  
\*电源适配器与无线充电发射板需要另外购买。

#### 连接笔记本电脑充电




① 将USB电源线一端连接笔记本电脑USB接口，另一端连接移动电源。  
② 电量指示灯点亮，开始为移动电源充电。充电开始后，电量指示灯，根据电量的多少闪烁，同时指示灯闪烁的位置，会随着电量的增加而移动。

#### 连接台式电脑充电





① 将USB电源线一端连接台式电脑主板USB接口，另一端连接移动电源。  
② 电量指示灯点亮，开始为移动电源充电。充电完成后，4个电量指示灯会保持常亮，此时充电完成，可以将充电器移除。

#### 对手机进行无线充电



① 双击触摸式开关，电源指示灯点亮并显示剩余电量，无线充电指示灯蓝绿交替闪烁后熄灭。  
② 将带无线充电功能的手机置于充电板上，听到“滴”一声开始充电。无线充电指示灯显示为蓝色，当充电板发出连续的提示音时，请重新放置手机。  
\*当手机离开移动电源30秒，无线充电自动关闭，如再充电需要重新触摸启动。

#### 通过USB对设备进行充电



① 将USB电源线一端连接移动电源USB输出接口，另一端连接手机充电接口。  
② 对手机进行USB充电，同时可支持对另一台手机进行无线充电。  
③ 本产品USB充电能为平板电脑、MP3、PSP、数码相机等移动设备提供充电。

#### 规格参数


电池类型：聚合物锂电池 电池容量：4000mA  
输入电压：DC5V, 2A MAX 输出电压：DC5V, 2.1A  
规格尺寸：105\*72\*20mm 产品重量：135g

#### 注意事项


1. 请勿挤压或碰撞。
2. 请勿自行拆卸或投入火中、水中，避免造成短路漏电，避免损坏电路出现漏电现象。
3. 请勿在严重高温、潮湿或腐蚀性环境下使用无线充电器，避免损坏电路出现漏电现象。
4. 请勿与带磁条或者芯片的磁卡（身份证、银行卡等）放置太近，避免造成磁卡丢失。
5. 请保持植入医疗设备（心脏起搏器、植入性耳机等）与无线充电器之间的距离至少为20cm，以避免对医疗设备造成潜在干扰。
6. 应看管好儿童，以确保他们不将无线充电器当成玩具来玩，以避免不必要的意外。

说明书涉及图片均为示意图，最终产品以实物为准。  
内含：无线充电移动电源、30cm电源线、150cm电源线、产品说明书

### Portable Wireless Charging Power Bank User Manual




#### Connect to Power Adapter




This product have two kinds of charging ways as below:  
① Connect the power adapter to socket.  
② Connect the USB cable to adapter and the other end to the wireless power bank.  
③ Connect the USB cable to adapter and the other end to the wireless charging pad, put the bottom side of power bank on wireless charging pad for wireless charging.  
\*Power adapter and wireless charging pad not included, pay additional if you need.

#### Connect to Laptop for Charging




① Connect the USB2.0 interface into laptop USB port, the other Micro USB to power bank.  
② It shows start charging the power bank when LED light on, and battery indicator light will flash when charging and battery capacity increase.

#### Connect to Desktop for Charging





① Connect the USB2.0 interface into desktop motherboard USB port, the other Micro USB to power bank.  
② It shows start charging the power bank when LED light on, and the four power indicator light keeps on after fully charged. Please move the power bank away from power supply.

#### Charge your mobile phone wirelessly



① Touch the switch twice, the power indicator light on and display the remaining power capacity, wireless charging indicator light will turn off after blue light and green light flash alternately.  
② Putting the mobile phone with function of wireless charging on charging pad, it's start to charging when hear "Di" sound, and the wireless charging indicator light turn to blue. Please put phone again when the charging pad send a continuous beep.  
\*The wireless charging will shut down automatically if mobile phone leave mobile power bank for 30 seconds, and please touch start again if need charging.

#### Charging device with micro USB



① Connect portable power bank to USB2.0 interface, the other micro USB to the mobile phone charging interface.  
② Charge your phone via USB cable and charge the other phone wirelessly.  
③ This USB charging for tablet PC, MP3, PSP, digital camera and other mobile devices.

#### Specification

Battery: Polymer Li-Ion Battery 电池容量: 4000mA  
Input voltage: DC5V, 2A MAX 输出电压: DC5V, 2.1A  
Dimensions: 105\*72\*20mm 产品重量: 135g

#### Notes:

1. Do not squeeze or collid.
2. Do not disassemble or throw into fire or water, to avoid causing a short circuit leakage.
3. Do not use wireless charger in severely hot, humid or corrosive environments, to avoid circuit damage and occurs leakage phenomenon.
4. Do not place too close with magnetic stripe or chip card (ID card, bank cards, etc.) to avoid magnetic failure.
5. Please keep the distance at least 20cm between implantable medical devices (pacemakers, implantable cochlear, etc.) and the wireless charger, to avoid potential interference with the medical device.
6. To take care of the children, to ensure that they won't play the wireless charger as a toy, to avoid unnecessary accidents.

The involved images are sketch maps, the final product as per the material subjects.  
Includes: wireless charger, 30cm power cable, 150cm power cable, user's manual.